



**Calhoun: The NPS Institutional Archive**  
**DSpace Repository**

---

Faculty and Researchers

Faculty and Researchers' Publications

---

2004

## Overview of Antennas for UAVs, Presentation

Jenn, David

Monterey, California. Naval Postgraduate School

---

<https://hdl.handle.net/10945/41707>

---

This publication is a work of the U.S. Government as defined in Title 17, United States Code, Section 101. Copyright protection is not available for this work in the United States.

*Downloaded from NPS Archive: Calhoun*



Calhoun is the Naval Postgraduate School's public access digital repository for research materials and institutional publications created by the NPS community. Calhoun is named for Professor of Mathematics Guy K. Calhoun, NPS's first appointed -- and published -- scholarly author.

**Dudley Knox Library / Naval Postgraduate School**  
**411 Dyer Road / 1 University Circle**  
**Monterey, California USA 93943**

<http://www.nps.edu/library>

---

# Overview of Antennas for UAVs


---

Prof. David Jenn  
833 Dyer Road, Room 437  
Monterey, CA 93943  
(831) 656-2254  
jenn@nps.navy.mil  
<http://web.nps.navy.mil/~jenn>

# Antenna Systems for UAVs

---

- Antennas are required for a wide variety of UAV systems
- Antenna requirements depend on the specific platform and mission:
  - > Radar/Electronic Warfare
  - > Communications
  - > Data links
  - > GPS/geolocation
  - > Other sensors (biological, chemical, etc.)
- Ground station antennas not addressed here




# UAV Antenna Issues

---

- For airborne applications:
  - > Size, weight, power consumption
  - > Power handling
  - > Location on platform and required field of view (many systems compete for limited real estate)
  - > Many systems operating over a wide frequency spectrum
  - > Isolation and interference
  - > Reliability and maintainability
  - > Radomes (antenna enclosures or covers)
- Accommodate as many systems as possible to avoid operational restrictions
- Signatures must be controlled: radar cross section (RCS), infrared (IR), acoustic, and visible (camouflage)
- New architectures and technologies are being applied to UAVs

# Antenna Performance Measures

- Gain, rule of thumb:  $G = 4\pi Ae / \lambda^2$ 
  - >  $A$  = area,  $\lambda$  = wavelength
  - >  $e$  = efficiency ( $0 < e < 1$ )
- Field of view or beamwidth
  - > usually half power, HPBW,  $\theta_B$
- Polarization
- Sidelobe level
  - > maximum
  - > average
- Antenna noise temperature,  $T_A$
- Operating bandwidth
  - > instantaneous
  - > tunable
- Radar cross section
  - > in band
  - > out of band



# “New” Antenna Technologies for UAV Applications


---

- Some “new” concepts have been around since the 1960s, but have only recently become practical due to advances in computers and micro devices
- New technologies and architectures include:
  - > Solid state (active antennas)
  - > Conformal
  - > Smart antennas (“smart skins” or “living skins”)
  - > Superconductivity
  - > Genetic algorithms
  - > Wide band (shared apertures)
  - > Frequency selective devices and surfaces
  - > New and exotic materials
  - > Adaptive
  - > Reconfigurable
  - > Multiple beams
  - > Photonics
  - > Digital beamforming
  - > Fractal antennas

Note: Most of these terms are not precisely defined and they are not mutually exclusive. An antenna can fall into multiple categories.

# Antenna Installation Options

---




- The choice may limit operation of the system or degrade its performance
- Externally mounted
  - > structural/environmental stress
  - > if non-retractable, always in view
  - > if retracted, system unusable
- Conformal surface mounted
  - > aerodynamic (low profile)
  - > curvature complicates design and manufacture
- Radome enclosures
  - > controlled environment
  - > inefficient use of volume
  - > radome loss
  - > wider field of view (FOV)
  - > includes “pods”

# Motivation for Wide Bandwidth

- Bandwidth is the range of frequencies over which the antenna has “acceptable” performance
- Trend is toward wide band wave forms
  - > low probability of intercept
  - > frequency hopping
  - > multiple channels (i.e., orthogonal frequency division multiplexing)
  - > high resolution and data rates
- Shared aperture (multi-mission) antenna: a single antenna used for all EM sensors (radar, EW, comms, etc.)

- Definitions (not standardized)
  - > narrow band: < 2%
  - > wide band: 2-10%
  - > ultra wide band: > 10%



$$\text{Bandwidth, } B = f_H - f_L$$



$$\text{Center frequency, } f_o = (f_H + f_L) / 2$$





# Wide Bandwidth Approaches

- Single radiating structure that operates over the entire frequency band

$$d_{\max} > \frac{\lambda}{2} > d_{\min}$$




- Collection of nested or integrated narrow band antennas




# Frequency Selective Surfaces (FSS)

- Example of a FSS element (tripoles)




- Band-stop frequency characteristic





- Applications:

- > stealth -- shield antennas at high out of band frequencies
- > antennas -- reflector antennas; array ground planes (below)




# Multiple Beams

- Multiple beams share the same aperture (they exist simultaneously)
- Cover large spatial volumes quickly
- Receiver on each beam  
(increases the system bandwidth)
- Beam coupling losses
- Increased complexity




REFLECTOR




LENS

BUTLER




BLASS




# Active vs. Passive Antenna

- Receive architecture



- Can be applied to transmit antennas using power amplifiers
- Transmit and receive channels are packaged together to form T/R modules


# Digital Beamforming (DBF)




- The complex signal ( $I$  and  $Q$ , or equivalently, amplitude and phase) are measured and fed to the computer
- Element responses become array storage locations in the computer
- The weights are added and the sums computed to find the array response
- In principle any desired beam characteristic can be achieved, including multiple beams

# Digital Beamforming (DBF)

- Direct conversion to baseband is preferred, but high speed A/Ds are a problem
- Receive channel: (down conversion using two mixing stages)




- Transmit channel (up conversion using one mixing stage)



# Conformal Antennas

---




- Conformal antenna apertures conform to the shape of the platform
- Typically applied to composite surfaces; the antenna beamforming network and circuitry are interlaced with the platform structure and skin
- Can be active antennas with processing embedded (i.e., adaptive or “smart”)
- Self-calibrating and fault isolation (errors and failures detected and compensated for or corrected)
- Can be re-configurable (portion of the aperture that is active can be changed)
- Infrared (IR) and other sensors can be integrated into the antenna


# Mutual Coupling

- Elements in an array interact with each other (patterns of edge elements deviate from those in the center)
- Example: 10 element array (element 1 is at edge; element 5 at center)

Individual dipole element H-plane patterns (infinite ground plane )




Infinite vs. finite ground plane







# Conformal Shapes

- Curvature must be considered in the design process, or pattern distortion occurs
- Example below: finite ground plane, mutual coupling included




FLAT GROUND PLANE

CURVED GROUND PLANE



# Patch Antennas


- Lend themselves to printed circuit fabrication techniques
- Low profile - ideal for conformal antennas
- Circular or linear polarization determined by feed configuration
- Difficult to increase bandwidth beyond several percent
- Substrates support surface waves
- Lossy
- Feeding methods:




# True Time Delay for Wide Band Scanning

- For wideband scanning the phase shifter must provide true time delay

BEAM SCANNING USING CABLES TO PROVIDE "TRUE TIME DELAY"




BEAM SCANNING WITH PHASE SHIFTERS GIVES A PHASE THAT IS CONSTANT WITH FREQUENCY




# Fiber Optic Beamforming


- Fiber optic beamforming architecture and T/R module
- Conversion loss from microwaves to light > 20 dB (as of 1998)




# Photonic Time Delay Phase Shifters



# Photonics for Reconfigurable Arrays



- High energy beams are used to produce conducting antenna-shaped regions (left)
- Laser excitation of the switch activates a particular portion of the aperture (below)



# MMIC

---

- Monolithic microwave integrated circuit (MIMIC): All active and passive circuit elements, components, and interconnections are formed into the bulk or onto the surface, of a semi-insulating substrate by some deposition method (epitaxy, ion implantation, sputtering, evaporation, or diffusion)
- Technology developed in late 70s and 80s is now common manufacturing technique
- Advantages:
  - > Potential low cost
  - > Improved reliability and reproducibility
  - > Compact and lightweight
  - > Potentially broadband
  - > Design flexibility and multiple functions on a chip
- Disadvantages:
  - > Unfavorable device/chip area ratios
  - > Circuit tuning not possible
  - > Troubleshooting is a problem
  - > Coupling/EMC problems
  - > Difficulty in integrating high power sources

# Smart Antennas


---

- Antennas with built-in multi-function capabilities and processing are often called smart antennas
- If they are conformal as well, they are known as smart skins
- Functions include:
  - > Self calibrating: adjust for changes in the physical environment (i.e., temperature)
  - > Self-diagnostic (built-in test, BIT): sense when and where faults or failures have occurred
- Tests can be run continuously (time scheduled with other system functions) or run periodically
- If problems are diagnosed, actions include:
  - > Limit operation or shutdown the system
  - > Adapt to new conditions when processing, or reconfigure the antenna




# T/R Module Concept


- Transmit and receive channels for each element are side by side
- Depth is a disadvantage, but module replacement easy



- F-15 radar




# T/R Tile Concept




- Low profile
- A point failure requires that the entire tile be replaced

From paper by Gouker, Delisle and Duffy, *IEEE Trans on MTT*, vol 44, no. 11, Nov. 1996




# Radomes



- Radome must be transparent in the operating band
- Protects the antenna from the environment
- The antenna pattern with a radome will always be different than that without a radome
- Radome effects on the antenna pattern:
  1. beam pointing error from refraction by the radome wall
  2. gain loss due to loss in the radome material and multiple reflections
  3. increased sidelobe level from multiple reflections

# Superconductivity

- Reduces loss in feed lines (as much as 25 dB for a 16 element array operating at 60 GHz)




- Makes possible “super-directive” arrays
  - > gain much higher than expected for the given array area
  - > requires some feed lines to have very high current, and therefore  $I^2R$  losses are prohibitive in conventional conductors

# Antenna Temperature


---

- Antenna noise temperature is specified in degrees Kelvin
- Indication of the noise power out of the antenna when no signal is present
- Depends on background radiation
- Especially important when very low signal power is expected



# Example: Mini- and Micro-SAR

---



MiniSAR installed

<http://www.imicrosensors.com/>

- MicroSAR

- 0.3 m Resolution
- 2 km Sensor Range
- 1 lb Payload
- Ka-band Radar Design
- Innovative Motion Compensation
- Suitable for mini UAVs
- May be Further Miniaturized for MAVs

- MiniSAR


- 0.1 m Resolution SAR
- 10 km Sensor Range
- MTI Mode
- 15 lb Payload
- Ku-Band

# Vertical Takeoff UAV


---

- USN VTUAV has multiple missions
- Use EM simulation codes to study
  - > antenna placement
  - > effect of nearby structure on patterns
  - > interference with other systems


VTUAV mesh model



Pitch, roll, and yaw patterns



# JSOW Captive Carry



Gain specification  
(dashed)

HPBW contour of  
captive antenna  
(solid)

- Problems similar to a UAV
  - > blockage
  - > radome losses

